



- 1 Power switch
- 2 Ch A volume control and LED indicator
- 3 Ch B volume control and LED indicator
- 4 Audio input volume controls
- 5 MP3 input with volume control
- 6 REC output with volume control



- 7 PAGE INPUT/OUTPUT
- 8 FIRE ALARM
- 9 EQUALIZER
- 10 INPUTS
- 11 5-Band graphic equalizer
- 12 RS-232 connectivity
- 13 Emergency alert (panic) output
- 14 Aux input with mic/line level switch
- 15 Computer input with GLI switch
- 16 DVD input twin RCA jack
- 17 Two Sensor inputs RCA jack
- 18 5V USB charging port
- 19 DC 1 9V 3.42A input